


Jun.1.2024 Copyright 2024 HIROSE ELECTRIC CO., LTD. All Rights Reserved.
In case of consideration for using Automotive equipment / device which demand high reliability, kindly contact our sales window correspondents.




Jun.1.2024 Copyright 2024 HIROSE ELECTRIC CO., LTD. All Rights Reserved.
In case of consideration for using Automotive equipment / device which demand high reliability, kindly contact our sales window correspondents.


DF57 Series Mating / Unmating Operation Instruction (For DF57 series)

Mating


①By positioning the convexity of the socket sides to the header concavity, align the centers of the socket and the header in pitch direftion.



②Slightly press the socket down at cable side to tilted angle.




③Press down at the lever side with stabilizing the cable side to insert. Mating completes.




Unmating


①Hook the lever with finger nail.



②Lift up to the upper difrection and friction lock is released.



③Lift up to the upper direction and positive lock is released. Removal completes.



DRAWING NO.	EDC3-343903-01
PART NO.	DF57H-6S-1.2C
CODE NO.	CL666-0103-4-00