Apr.1.2024 Copyright 2024 HIROSE ELECTRIC CO., LTD. All Rights Reserved.
In case of consideration for using Automotive equipment / device which demand high reliability, kindly contact our sales window correspondents.







NOTES 1. The dimension in parentheses are for reference.
2. Lead co-planarity including reinforced chucking metals shall be 0.1 max.
3. To be delivered with tape and reel packages.
4. Note that preventive hole for sink mark or slit could be added for improvement.
5. The quality remains good, even with the dark spots, which could occasionally occur on molded plastic.
6. This product satisfies halogen free requirements defined as 900ppm maximum chlorine, 900ppm maximum bromine, and 1500ppm maximum total of chlorine and bromine.
7 Shows hook part of the chucking metal.

RECOMMENDED PCB MOUNTING PATTERN



RECOMMENDED STENCIL PATTERN

(Recommended stencil thickness:t=0.1)



NO.	MATERIAL	FINISH , REMARKS	NO.	MATERIAL	FINISH , REMARKS
4	PHOSPHOR BRONZE	(CONTACT AREA·LEAD) GOLD PLATING 0.03μm MIN OVER NICKEL 1μm MIN. (OTHER) NICKEL PLATING 1μm MIN.	9	(CONNECTOR)	
3	PHOSPHOR BRONZE	(CONTACT AREA·LEAD) GOLD PLATING 0.03μm MIN OVER NICKEL 1μm MIN. (OTHER) NICKEL PLATING 1μm MIN.	8	POLYSTYRENE	
2	PA	BLACK UL94V-0	7	POLYESTER	
1	LCP	BEIGE UL94V-0	6	POLYSTYRENE	
			5	PHOSPHOR BRONZE (PLATED MATERIAL)	TIN PLATING (REFLOW FINISHED)1μm MIN.

UNITS	SCALE		COUNT	DESCRIPTION OF REVISIONS	DESIGNED	CHECKED	DATE
mm	15 : 1	△0					

HIROSE ELECTRIC CO., LTD.

APPROVED	NF. MIYAZAKI	16.11.14	DRAWING NO. EDC-372294-00-00
CHECKED	YH. MICHIDA	16.11.11	PART NO. FH64MA-7S-0.25SHW
DESIGNED	HY. YAMAZAKI	16.11.11	CODE NO. CL580-4610-0-00 △0 1/8
DRAWN	KY. KIKUCHI	16.11.11	

HRS DRAWING FOR REFERENCE

Apr.1.2024 Copyright 2024 HIROSE ELECTRIC CO., LTD. All Rights Reserved.
In case of consideration for using Automotive equipment / device which demand high reliability, kindly contact our sales window correspondents.

RECOMMENDED FPC (20:1)

(Exposed conductor area thickness:t=0.12±0.02)





HRS DRAWING FOR REFERENCE

FPC CONFIGURATION (REFERENCE EXAMPLE)

(FREE)



MATERIAL NAME	MATERIAL	THICKNESS(μm)
Covering film layer.	Polyimide 1mil	25
Cover adhesive		25
Surface treatment	1μm to 6μm nickel underplated 0.2μm gold plated	(4)
Copper foil	Cu 1/2 oz	18
Base adhesive	Heat-hardened adhesive	No adhesion material
Base film	Polyimide 1mil	25
Reinforcement material adhesive	Heat-hardened adhesive	30
Stiffener	Polyimide 2mil	50

NOTES
8 Shows recommended dimension when lead for plating is required.
9 Dimention M must be 0.5mm minimum.
10 Indicated tolerance is applicable to the exposed conductor.
11 Both end side of contact pad on FPC can not be used for signal transmission.

<RECOMMENDED FPC>

DRAWING NO.	EDC-372294-00-00
PART NO.	FH64MA-7S-0.25SHW
CODE NO.	CL580-4610-0-00

Apr.1.2024 Copyright 2024 HIROSE ELECTRIC CO., LTD. All Rights Reserved.
In case of consideration for using Automotive equipment / device which demand high reliability, kindly contact our sales window correspondents.

EMBOSSED CARRIER TAPE DIMENSION (5:1)



REEL DIMENSION (FREE)



NOTES 12. Per reel : 5000 connectors.
13. Refer to JIS C 0806 and IEC 60286-3
(Packaging of components for automatic handling.)

LEADER, TRAILER DIMENSION (FREE)



HRS DRAWING FOR REFERENCE

<PACKING SPACIFICATIONS>

HRS	DRAWING NO.	EDC-372294-00-00
	PART NO.	FH64MA-7S-0.25SHW
	CODE NO.	CL580-4610-0-00

Apr.1.2024 Copyright 2024 HIROSE ELECTRIC CO., LTD. All Rights Reserved.
In case of consideration for using Automotive equipment / device which demand high reliability, kindly contact our sales window correspondents.

HRS DRAWING FOR REFERENCE

This connector features small and thin, requiring delicate and careful handling.
To prevent connector/FPC breakege and contact failure (meting failure, FPC pattern breakage, etc), read through the instructions shown below and handle the connector properly.

【Connector Part Nomenclature】



Top view



Front view



Odd numbered contact view



Even numbered contact view

Chucking metal view

【Operation and Precautions】

1. Initial condition

Actuator does not have to be operated before inserting FPC, as the connector is delivered with the actuator opened.

【Caution】
-Do not close the actuator before inserting FPC.
Closing the actuator without FPC could make the contact gap smaller, which could increase the FPC insertion force. (Example1)
-Do not insert FPC or operate actuator before mounting. (Example1)

Example1



- Open when deliverd -



- Incorrect operation -

2. How to insert FPC

Insert the FPC into the connector opening horizontally to the PCB plane.
Insert it properly to the very end. (Example2)

【Caution】
-Do not insert the FPC with the actuator closed. (Example3)
-Do not twist the FPC to up and down, right and left or an angle. (Example4)

Example2



- Correct operation -



- Correct operation -

Example3



- Incorrect operation -



- Incorrect operation -

Example4



- Incorrect operation -



- Incorrect operation -

3. FPC insertion check

Make sure that the FPC tabs are located in proper position as shown in the figure below after FPC insertion. (Example5)

【Caution】
-Do not insert the FPC at an angle and/or stop it before insertion is completed. (Example6)(Example7)

Example5



- Correct assembled -



Example6



- Incorrect assembled -
(Insufficiently inserted)



Example7



- Incorrect assembled -
(Angle insertion)



<INSTRUCTION MANUAL (1)>

DRAWING NO.	EDC-372294-00-00
PART NO.	FH64MA-7S-0.25SHW
CODE NO.	CL580-4610-0-00

Apr.1.2024 Copyright 2024 HIROSE ELECTRIC CO., LTD. All Rights Reserved.
In case of consideration for using Automotive equipment / device which demand high reliability, kindly contact our sales window correspondents.

HRS DRAWING FOR REFERENCE

4. How to lock

The actuator rotates around the rotational axis as shown below.
Apply load to rotate the actuator by 90 degree after inserting the FPC. (Example8)

[Caution]
-To close the actuator, operate at the center of the actuator. (Example9)
-To close the actuator, do not operate the actuator at one end only. (Example10)
-Do not rotate the actuator to the counter direction. (Example11)
-Do not push out the actuator horizontally. (Example12)
-Do not push out the actuator vertically. (Example13)
-Do not operate the actuator while the upper contact arm is pressed down. (Example14)
-Do not pick the actuator to lift. (Example15)
-Operate the actuator by hand without using sharp tool such as Tweezers. (Example16)
-Do not apply excess force to the housing during the operation. (Example17)

Example8 [Actuator movable range] (Side view)



Example9 OK

Close the actuator at the center



- Correct operation -

Example10 NG

Do not operate the actuator at one end only



- Incorrect operation -

Example11 NG



- Incorrect operation -

Actuator receives inappropriate force in reverse direction.

Example12 NG



- Incorrect operation -

Example13 NG



- Incorrect operation -

Example14 NG



Upper arm of contact is locked and unable to displace.

- Incorrect operation -

Example15 NG



- Incorrect operation -

Example16 NG



- Incorrect operation -

Example17 NG

Do not apply excess force to the housing during the operation.



- Incorrect operation -

5. Mating confirmation of the FPC

Visually confirm the FPC positioning after closing the actuator. (Example18)

[Caution]
-Do not insert the FPC at an angle and/or stop it before insertion is completed. (Example19)(Example20)

Example18 OK



- Correct assembled -

Example19 NG



- Incorrect assembled - (Insufficiently inserted)

Example20 NG



- Incorrect assembled - (Angle insertion)







<INSTRUCTION MANUAL(2)>

DRAWING NO.	EDC-372294-00-00
PART NO.	FH64MA-7S-0.25SHW
CODE NO.	CL580-4610-0-00

Apr.1.2024 Copyright 2024 HIROSE ELECTRIC CO., LTD. All Rights Reserved.
In case of consideration for using Automotive equipment / device which demand high reliability, kindly contact our sales window correspondents.

6. How to unlock

Slowly flip up the actuator to release the lock.(Example21)

[Caution]
-To open the actuator, operate at the center of the actuator.(Example22)
-To open the actuator, do not operate the actuator at one end only.(Example23)
-The actuator is opened up to the movable limit, 90 degree.(Example24)
Do not open the actuator beyond the specified degree or apply excess force to the actuator.
-Open the actuator right above.
Do not attempt to open further or to open it by applying horizontal force as this may cause its damage.(Example25)
-Do not pick the actuator to lift.(Example26)
-Operate the actuator by hand without using sharp tool such as Tweezers.(Example27)
-Do not apply excess force to the housing during the operation.(Example28)
-Please note that the connector is back flip style connector,
and the opening for FPC insertion and the actuator face the opposite direction.
Do not try to lift the actuator at the FPC insertion opening side.(Example29)

Example21 OK



- Correct operation -

Example22 OK



- Correct operation -

Example23 NG



- Incorrect operation -

Example24 NG



- Incorrect operation -

Example25 NG



- Incorrect operation -

- Incorrect operation -

Example26 NG



- Incorrect operation -

Example27 NG



- Incorrect operation -

Example28 NG



- Incorrect operation -

Example29 NG



- Incorrect operation -

HRS DRAWING FOR REFERENCE

<INSTRUCTION MANUAL(3)>

DRAWING NO.	EDC-372294-00-00
PART NO.	FH64MA-7S-0.25SHW
CODE NO.	CL580-4610-0-00

Apr.1.2024 Copyright 2024 HIROSE ELECTRIC CO., LTD. All Rights Reserved.
In case of consideration for using Automotive equipment / device which demand high reliability, kindly contact our sales window correspondents.

7. How to remove FPC

After rotating the actuator to the fully opened position carefully withdraw the FPC pulling out horizontally. (Example30)

[Caution]
-For FPC removal, do not pull out the FPC upward or angled direction. (Example31)
-Do not attempt to pull the FPC without unlocking the actuator (Example32).

Example30 OK



- Correct operation -



- Correct operation -

Example31 NG



- Incorrect operation -



- Incorrect operation -

Example32 NG



- Incorrect operation -



- Incorrect operation -

[Precautions for component layout]

Depending on a FPC rounding, a load is applied to the connector, and a contact failure may occur.
To prevent a failure, take the following notes into a consideration during mechanism design.

[Caution]
-Avoid applying forces to FPC in vertical or horizontal directions. (Example33)(Example35)
In addition, avoid pulling up and down on the FPC.
-When fixing FPC after FPC cabling, avoid pulling FPC, and route the wire FPC with slack.
In this regard, the stiffener is parallel to the PCB. (Example34)
-During FPC wiring , ensure that stress is not applied directly to the connector.
Do not bend the FPC excessively near the connector during use , or it may cause contact failure or FPC breakage.
Stabilizing the FPC is recommended. (Example35)
-Do not mount other components touching to the FPC underneath the FPC stiffener. (Example36)
-Make adjustments with the FPC manufacturer for FPC bending performance and wire breakage.
-Keep a sufficient FPC insertion space in the stage of the layout in order to avoid incorrect FPC insertion.
Appropriate FPC length and component layout are recommended for assembly ease.
Too short FPC length makes assembly difficult.
-Keep spaces for the actuator movement and its operation for PCB design and component layout.

Example33 NG



Example34 OK



Example35 NG



Example36



HRS DRAWING FOR REFERENCE

<INSTRUCTION MANUAL(4)>

HRS	DRAWING NO.	EDC-372294-00-00
	PART NO.	FH64MA-7S-0.25SHW
	CODE NO.	CL580-4610-0-00

Apr.1.2024 Copyright 2024 HIROSE ELECTRIC CO., LTD. All Rights Reserved.
In case of consideration for using Automotive equipment / device which demand high reliability, kindly contact our sales window correspondents.

HRS DRAWING FOR REFERENCE

[Instructions for mounting on the PCB]

Follow the instructions shown below when mounting on the PCB.

[Caution]
-Refer to recommended layouts on the page 1 for PCB and stencil pattern.
-Shorter pattern width than the recommended PCB dimension,
could cause solder wicking and/or flux penetration.
-Larger pattern than the recommended stencil dimension,
could cause solder wicking and/or flux penetration.
-Clearance underneath the contact and the housing is very small.
In case solder resist and/or silk screening are applied on PCB underneath the connector,
verify the thickness, or it could push up the connector bottom
and may cause soldering defect and/or insufficient fillet formation.
-Apply reflow temperature profile within the specified conditions.
In individual applications, the actual temperature may vary,
depending on solder paste type, volume/thickness and PCB size/thickness.
Consult your solder paste and equipment manufacturer for specific recommendations.
-Prevent warpage of PCB, where possible, since it can cause soldering failure
:even with 0.1 mm max coplanarity.
-When mounting on the flexible board, please make sure to put a stiffener
on the backside of the flexible board.
We recommend a glass epoxy material with the thickness of 0.3 mm min.
-Do not add 0.5 N or greater external force when unreel or pick and place the connector etc,
or it may get broken.

[Instructions for PCB handling after mounting the connector]

Follow the instructions shown below when mounting on the PCB.

[Caution]
- ·Splitting a large PCB into several pieces
·Screwing the PCB
Avoid the handling described above so that no force is exerted on the PCB during the assembly process.
Otherwise, the connector may become defective.
-The warp of a 100 mm wide PCB should be 0.5 mm or less.
The warp of PCB suffers stress on connector and the connector may become defective.(Example 37)

Example 37



[Instructions on manual soldering]

Follow the instructions shown below when soldering the connector manually during repair work, etc.

[Caution]
-Do not perform manual soldering with the FPC inserted into the connector.
-Do not heat the connector excessively. Be very careful not to let the soldering iron contact
any parts other than connector leads. Otherwise, the connector may be deformed or melt.
-Do not supply excessive solder (or flux).
If excessive solder (or flux) is supplied on the terminals or chucking metals, solder or flux may adhere to the contacts
or rotating parts of the actuator, resulting in poor contact or a rotation failure of the actuator.
Supplying excessive solder to the chucking metals may hinder actuator rotation,
resulting in breakage of the connector.

<INSTRUCTION MANUAL(5)>

HRS	DRAWING NO.	EDC-372294-00-00
	PART NO.	FH64MA-7S-0.25SHW
	CODE NO.	CL580-4610-0-00 △0 8/8