



## DF57 Series Mating / Unmating Operation Instruction


①By positioning the convexity of the socket sides to the header concavity, align the centers of the socket and the header in pitch direftion.

②Slightly press the socket down at cable side to tilted angle.

@Press down at the lever side with stabilizing t he cable side to insert. Mating completes.










## Unmating

①Hook the lever with finger nail.





③Lift up to the upper direction and positive lock is released. Removal completes.



ĸ	DRAWING NO.	EDC3-349275-01		
	PART NO.	DF57H-*S-1.2C(08	)	
	CODE NO.	C L 6 6 6 -	$\triangle$	2/2

FORM HC0011-5-8\_AN