Precautions

<Pre><Pre>cautions at Time of Insertion>

Align with the connector form and press down continue pressing until there is a tactile click.

Handing


Method: Lightly grasping the base the cable, press the connector with your finger and insert it.

Insertion Angle

Caution: Do not insert at an angle of 30° or greater.

Doing so will cause contact deformation or case damage.

Method: Insert with the connector parallel.



<Pre><Pre>cautions at Time of Disconnection>

Align with the connector form and press down continue pressing until there is a tactile click.

Handing

Method: Grasp the cable so that the entire cable is pulled evenly and it out.

Angle of Removal

Caution: Do not remove at an angle of 30° or greater.

Doing so will cause contact deformation or case damage.

Method: Remove with the connector parallel.

