



## Operation Procedures for Floating Socket


## [ Mating ]

1. Hold part A on the floating socket, and place it on the receptacle so that part A matches to part B. 2. Align the floating socket edge on the side of friction lock to receptacle housing edge in a line. (Forcible mating without above alignment process could cause contact deformation.)

3. Press down at the center surface of the floating socket. (Press down until the floating socket touches to the receptacle.)








## [ Unmating ]

Finger position

Unmating

2. After releasing either side, hook the lever on the other side with a finger and lift up



1		図番:	EDC3-330595-01	
	HR5	製品名:	DF59-4P-2FC(50)	
			製品 コード	CL667-0008-0-50 A 2
			7	0

FORM HC0011-5-4\_AN