

TITLE:	BM56G Series Guideline	ETAD-H1035-00
PRODUCT:	MULTI RF BOARD TO FPC CONNECTOR Pitch:0.35mm, Width:2.2mm Stacking height:0.6mm	PAGE: 1 OF 13

BM56G Series Guideline

	Approver	WR.FUKUCHI		202201	21
	Checker	TY.OOI		202201	21
	Designer	KT.KUSAKA		202201	20
REVISIONS				RevNo	0
Designer	Checker	Approve	r	DATE	



TITLE:BM56G Series GuidelineETAD-H1035-00PRODUCT:MULTI RF BOARD TO FPC CONNECTOR
Pitch:0.35mm, Width:2.2mmPAGE: 2 OF 13

Stacking height:0.6mm

1.	Notice for Device Handling	3
	1.1 Notice for mechanical designing	3
	1.2 FPC fixing	3
	1.3 Allocation of other components around connector	4
	1.4 Marking for mating position	4
2.	Notice for PWB designing	5
	2.1 Recommended PWB pattern and connector location	5
	2.2 PWB designing	7
	2.3 FPC designing	7
3.	Notice for Mounting	8
	3.1 Metal mask design	8
	3.2 Fillet forming	8
	3.3 Reflow Profile	8
4.	Notice for Connector Handling	9
	4.1 Connector insertion operation	9
	4.2 Connector withdrawal operation	. 10
5.	RF Evaluation Board Design Information	. 11
6.	Additional information	. 13
	6.1 PWB cleaning	. 13
	6.2 PWB handling	. 13
	6.3 Connector storage	. 13
	•	



TITLE:	BM56G Series Guideline	ETAD-H1035-00
PRODUCT:	PRODUCT: MULTI RF BOARD TO FPC CONNECTOR Pitch:0.35mm, Width:2.2mm Stacking height:0.6mm	

1. Notice for Device Handling

1.1 Notice for mechanical designing

There is still possibility that connectors are disengaged if strong impact, such as dropping, is put against connectors in use. In order to prevent connectors from disengaging, please make sure to put buffer material between a connector and a cover case to hold down the connector pair to the mating direction. If a connector is directly pressed down by a cover case, there is a possibility that the cover case is bent and it may cause connector disengagement when the device is dropped. Please avoid a design that the connector is directly pressed by cover case, instead, use put the buffer material to press down the connector.

Buffer material must be the size which is able to cover all over the connector mounting area.



1.2 FPC fixing

If FPC position is fixed, connector will get direct stress from dropping impact. Please do not design FPC positioning bosses which prevent flexibility of FPC.





TITLE:	BM56G Series Guideline	ETAD-H1035-00
PRODUCT:	MULTI RF BOARD TO FPC CONNECTOR Pitch:0.35mm, Width:2.2mm Stacking height:0.6mm	page: 4 of 13

1.3 Allocation of other components around connector

Please do not locate any material which may effect on connector mating around the connectors.

Please do not locate any material inside the red dashed.



1.4 Marking for mating position

When mating a connector on the FPC side against the other side manually, in order to operate mating in the appropriate position without misalignment, please put some marking to indicate the exact mating position on the PWB.





TITLE:	BM56G Series Guideline	ETAD-H1035-00
PRODUCT:	MULTI RF BOARD TO FPC CONNECTOR Pitch:0.35mm, Width:2.2mm Stacking height:0.6mm	page: 5 of 13

2. Notice for PWB designing

2.1 Recommended PWB pattern and connector location

For the recommended PWB pattern, please see the product drawing.



Pad layout and contact position for receptacle (A-A), A'



Pad layout and contact position for receptacle (B-B), B'



Pad layout and shield position for receptacle (C-C), C'



Pad layout and shield position for receptacle (D-D), D'











D'



TITLE:	BM56G Series Guideline	ETAD-H1035-00
PRODUCT:	MULTI RF BOARD TO FPC CONNECTOR Pitch:0.35mm, Width:2.2mm Stacking height:0.6mm	page: 6 of 13





Pad layout and shield position for plug (E-E), E'





Pad layout and contact position for plug (F-F), F'





Pad layout and shield position for plug (G-G), G'



Pad layout and shield position for plug (H-H), H'





0.13



] H'



TITLE:	BM56G Series Guideline	ETAD-H1035-00
PRODUCT:	MULTI RF BOARD TO FPC CONNECTOR Pitch:0.35mm, Width:2.2mm Stacking height:0.6mm	page: 7 of 13

2.2 PWB designing

-Please design PWB layout properly so that front fillet, back fillet and side fillet are formed.

The recommended PWB layout is designed so that the connector can be soldered to the PWB appropriately. - In case that the pad layout is narrower than our recommendation, If the pad layout is not wide enough, there is

a possibility that solder wicking or flux splashing may occur.

Please contact and discuss with us if the PWB layout is different from the recommended PWB layout. -If there is not enough clearance on the inner side of PWB pattern, there is a possibility that the connector is pushed up by solder paste.

-In case those patterns are designed under a connector, there is a possibility to cause solder failure if there are physical height. Especially, in the following case, please conduct mounting test for the check.

2.3 FPC designing

Please make sure to put a stiffener on the backside of the FPC. Pad peeling or connector bent may occur.

[Note] Please consult HRS contact window when you use thinner stiffer than our recommendation.

Recommended thickness of stiffener F R - 4 : 0.3mm MIN S U S : 0.2mm MIN

Please consider the warpage of the FPC board when mounting. Warpage may occur during heating. (Max 0.02 mm at the center of the connector with reference to both ends of the connector).



TITLE:	BM56G Series Guideline	ETAD-H1035-00
PRODUCT:	MULTI RF BOARD TO FPC CONNECTOR Pitch:0.35mm, Width:2.2mm Stacking height:0.6mm	page: 8 of 13

3. Notice for Mounting

3.1 Metal mask design

For the recommended metal mask design, please see the product drawing.

3.2 Fillet forming



Likewise the other (receptacle) side, as the contact lead edge, on where "front fillet" is formed is a metal cut surface, phosphor bronze is exposed. The exposed area is easy to process thermal oxidation from reflow heating, so it is difficult for soldering paste to get wet and be spread over the area. If the fillet formation needs to be judged defective/not defective, please judge by "side fillet" forming.

3.3 Reflow Profile

For the recommended reflow profile, please see the product drawing.



TITLE:

PRODUCT:

MULTI RF BOARD TO FPC CONNECTOR Pitch:0.35mm, Width:2.2mm

Stacking height:0.6mm

PAGE: 9 OF 13

4. Notice for Connector Handling

4.1 Connector insertion operation

Please mate this connector by hands.

Manual for inserting operation

1) Find the alignment area with hand to locate the connector in the appropriate mating position. This connector has alignment chamber (guidance ribs) on receptacle side and R on plug side, so that the connector can be self-aligned.





2) When the connector comes to the appropriate position, the connector comes into the aligned position. If the connector comes into aligned position. It can be recognized by hand that the connector goes down.



3) When the connectors are in alignment position, the connector pair cannot be moved back and forth and around as they are mated in a parallel position. Please mate the connectors completely, by putting force in this condition.



4) Please make sure connectors are mated completely. If one side is floating or the connectors are mated at a slant, please unmate once, and then mate them once again, following the procedures above from the beginning.







TITLE:	BM56G Series Guideline	ETAD-H1035-00
PRODUCT:	MULTI RF BOARD TO FPC CONNECTOR Pitch:0.35mm, Width:2.2mm Stacking height:0.6mm	page: 10 of 13

4.2 Connector withdrawal operation

1) It is desirable to withdraw the connector in the vertical direction against mating direction. However, in the case connector has high pin counts or thinner FPC and stiffener, it makes more difficult to withdraw the connector in the vertical direction.





2) If it is difficult to withdraw the connector, please withdraw the connector diagonally against the contact pitch direction. Please carefully withdraw the connector from the width side as a strong load is put on the plug.



3) If the FPC is not strong enough, there is a possibility that contacts may be pulled off or broken. Please make sure to conduct the test on FPC to repeat operation several times in an early stage build. Please carefully withdraw the connector in the slanted direction, picking the FPC corner, as it can be a risk to put a strong load on contacts.





TITLE:	BM56G Series Guideline	ETAD-H1035-00
PRODUCT:	MULTI RF BOARD TO FPC CONNECTOR Pitch:0.35mm, Width:2.2mm Stacking height:0.6mm	PAGE: 11 OF 13

5. RF Evaluation Board Design Information

The followings are the examples of board layers, patterns, and cutout dimensions. For the recommended PWD pattern, please see the product drawing.

Please use the thickness' information of the each layers as a reference, and please modify/control the impedance of this product at $50\Omega \pm 10\%$.

Recommendation for the coaxial connector part is a Hirose's product: HK-LR-SR2 (K connector: 2.92mm).

Please optimize the BM56 and the coaxial (HK-LR SR2) part by cutting out the L2 layer.



Example: Pattern Width (mm)





TITLE:	BM56G Series Guideline	ETAD-H1035-00
PRODUCT:	MULTI RF BOARD TO FPC CONNECTOR Pitch:0.35mm, Width:2.2mm Stacking height:0.6mm	PAGE: 12 OF 13

Receptacle RF Evaluation Board: Example of the cutout dimension





Pin Assignment: Ex. S: RF Signal G: GND

Example of Cutout Dimension (mm)

Plug RF Evaluation Board: Example of the cutout dimension



Example of Cutout Dimension (mm)





6. Additional information

6.1 PWB cleaning

Do not wash the board because it may be cause malfunction of the connector.

6.2 PWB handling

In the operation which could give stress to the mounted connector, including cutting or bending PWB, keep soldering area from mechanical stress.

6.3 Connector storage

- 1) Void could be occurred on the housing surface due to high heat during reflow. In order to prevent this problem, avoid storing connectors under humid condition. For long term storage, keep them at humidity manageable place.
- Depending on the production LOT of the connector, its housing color could be varied, or ultraviolet during storage changes connector surface color. However, these color differences do not affect the connector performance.
- 3) During PWB assembly and module assembly, make sure not to apply excessive stress to the stored connectors.
- 4) Avoid storing connectors in dusty area, or it could cause contact failure.

End of report