





May.1.2024 Copyright 2024 HIROSE ELECTRIC CO., LTD. All Rights Reserved.
In case of consideration for using Automotive equipment / device which demand high reliability, kindly contact our sales window correspondents.




1> FIGURE OF INSERTION

HORIZONTALLY ○




DF57H-3S-1.2C



DIAGONAL ×



DF57-***SCF



NOTE 1> AVOID ANGLED INSERTION OF CRIMP CONTACT(DF57-***SCF) TO MAINTAIN PERFORMANCE RELIABILITY.


NO.		MATERIAL		FINISH . REMARKS		1	PBT	UL94V-0. NATURAL(WHITE)	
UNITS		SCALE		COUNT		DESCRIPTION OF REVISIONS		DESIGNED	CHECKED
mm		20 : 1		△		APPROVED : KI. AKIYAMA		12.02.21	12.02.21
HRS		HIROSE ELECTRIC CO., LTD.		DRAWN : TS. KUMAZAWA		12.02.20		DRAWING NO.	
						12.02.21		EDC3-332438-01	
						12.02.20		PART NO.	
						12.02.20		DF57H-3S-1.2C	
								CODE NO.	
								CL666-0012-0-00	
								△ 1/2	

May.1.2024 Copyright 2024 HIROSE ELECTRIC CO., LTD. All Rights Reserved.
In case of consideration for using Automotive equipment / device which demand high reliability, kindly contact our sales window correspondents.


DF57 Series Mating / Unmating Operation Instruction (For DF57 series)

Mating


①By positioning the convexity of the socket sides to the header concavity, align the centers of the socket and the header in pitch direction.



②Slightly press the socket down at cable side to tilted angle.




③Press down at the lever side with stabilizing the cable side to insert. Mating completes.




Unmating


①Hook the lever with finger nail.



②Lift up to the upper direction and friction lock is released.



③Lift up to the upper direction and positive lock is released. Removal completes.



HRS

DRAWING NO.	EDC3-332438-01
PART NO.	DF57H-3S-1.2C
CODE NO.	CL666-0012-0-00

△ 2/2